



Square Ornamental Frame

Assembly Instructions

Components:

Legs	x 4
Curved tubes	x 4
Panels	x 4
Straight tubes	x 4
Finial & large nut	x 1
Bolts 25mm	x 8
Bolts 32mm	x 4
Nuts	x 12
Ground Pegs	x 4

Tools required: 8mm spanner, cross-head screwdriver (NB. We have included a very basic spanner and screwdriver with this frame in case you do not have your own, better ones to hand).

1. Take the 4 Curved tubes and connect them at their tops by fitting the Finial through the 4 holes and attaching the nut to the underside. Do not fully tighten at this stage.
2. Fit the 4 panels to the outside of the curved tubes, overlapping the joints at the corners. The right hand end of each panel fits over the left hand end of the next panel to its right. Use the 25mm bolts (the shorter ones) to hold the panels in place and tighten them hand tight only.
3. Using the 32mm bolts (the longer ones) fit the 4 legs and 4 straight tubes to the bases of the curved tubes. The legs should be positioned on the outside of the curved tubes with their feet pointing outwards and the straight tubes should be on the outside of the legs. The right hand end of each straight tube should fit over the left hand end of the straight tube to its right.
4. Tighten all 12 nuts and bolts firmly using the screwdriver and spanner.
5. Tighten the finial firmly by holding the nut underneath with one hand and turning the finial with the other hand.
6. Set the frame in position on level ground and secure it firmly with a ground peg at each of the corners.
7. Plant your climbing plants in positions where they can easily reach the legs of the frame and start climbing.

We hope you find the assembly of your frame a straight forward and satisfying task and that you get many years of good use from it.

Any problems, please call the team on: 0117 9341799.