


KETTLER

Kettler GB Limited
Merse Road, North Moons Moat
Redditch, Worcestershire, B98 9HL

www.kettler.co.uk

We reserve the right to make technical changes.
Colour deviations may occur in printing.
All sizes and weights are approximate values.

Product Code : 0896611-7001
**Chelsea Steamer Chair,
Teak Oil Acacia**



Made in Vietnam



INFORMATION ABOUT YOUR FURNITURE

Please read the following:



Royal
Horticultural
Society

BY

KETTLER

Congratulations

KETTLER's excellent reputation for quality and durability means your KETTLER furniture will be a good investment for years to come. We set high standards for our furniture and use only the best materials available. We design our furniture for the way you want to live today; shape and comfort are the cornerstone of our collection. Your furniture is built to last and rigorously tested to provide you with many years of satisfied use.

Wood Furniture

Wood is a natural material which reacts to weather conditions. Depending on weather type, the wood can swell or dry resulting in crack formation. The risk can be minimised by cleaning and/or treating the furniture with oil at regular intervals and keeping it clean and dry.

Care and Cleaning

Remove dust regularly with a clean dry cloth. Use pads, mats and coasters under plates, glasses, cups, vases etc to protect them from scratches, spills, stains and heat damage. Wipe spills immediately to prevent staining.

Natural Acacia, Teak oiled finish: Your new outdoor furniture should be treated with oil directly after purchase and after that at regular intervals or at least once a year.

Furniture that has been outdoors for some time should be cleaned before being re-oiled. Wash/scrub with water and a mild cleaner. Rinse and leave to dry before applying a new coat of oil.

Acacia Furniture: The polyurethane finish is a liquid resin with a durable finish which is more resistant to spills and does not need as much protection. Dust regularly with a soft dry cloth and wipe dry. When required wipe with a moist (not wet) cloth. This will remove fingerprints and light dirt. When dirt or grime have built up clean with and dampened cloth and mild cleaner. Rinse and allow to air dry.

Warranty for home use



For manufacturing faults only.

The warranty applies to domestic use only. If the product is damaged through accidental damage or mis-use, your warranty will be void. Spare parts and touch up paints can be obtained from our website www.kettler.co.uk.

To register your warranty, visit www.kettler.co.uk.

Storage

During the winter months, it is advisable to store the furniture in a cool place to avoid the risk of cracking. Tailored protective covers are also available.

Maintenance

Screws should be tightened and fittings should be regularly checked.

Customer Service

Please go to: www.kettler.co.uk to find our detailed care instructions as well as to order touch up paint and spare parts.