



Primrose NSTRUCTION MANUAL

Wooden Arc Hammock

Congratulations on your purchase of Wooden Arc Hammock!

Please read all the instructions throughly before starting assembly.







Please retain these instructions for future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this product as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED









200 KG 1 PERSON CAPACITY ASSEMBLY



30 MIN. ASSEMBLY


TOOL ASSEMBLY

1




Insert wrench handle into the wrench head.

2




Use assembled socket wrench to tighten/loosen hardware.

HARDWARE


















PARTS












Do not firmly tighten the screws until the item is completely assembled.


PRODUCT ASSEMBLY

1









PRODUCT WARRANTY INFORMATION

Please contact our Customer Service department to notify us of any faults or damaged pieces and request a replacement to be sent. Photos evidence maybe required.

CONTACT US, WE'RE HERE 7 DAYS A WEEK TO HELP YOU!





