

# **ELITE GARDEN ARCH**


ELITEARCH - 250cm [H] x 100cm [W] x 44.5cm [D]








### **PLAN**







www.grangefen.co.uk






# **ASSEMBLY INSTRUCTIONS**

# **ELITE GARDEN ARCH**

### PRESSURE TREATED GREEN



# **PARTS LIST**

- **Arch Side Sections** x 2
- **Curved Roof Beams** x 2
- **Dowling Beams** x 9

# HARDWARE PACK

[x] Screws 8 x 3.5cm

x10

#### **BEFORE YOU START**


- Check the pack/s and make sure that you have all of the parts listed above. If not, contact your retailer who will be able to help you.
- When you are ready to start, make sure you have the right tools to hand, plenty of space and a clean, dry area for assembly.

It is advisable for two people to carry out the work

#### SITE PREPARATION

Excavate a 30cm square hole (approx) for each post to a depth of at least 30cm. (see Fig.A right)

This will give your structure adequate stability.



#### **ASSEMBLY**

#### STEP 1


Take one of the Curved Roof Sections (B) and insert one of the Dowling Beams (C) into each of the holes provided.

### STEP 2

Take the second Curved Roof Section and position it onto the free end of the Dowling Beams.

Fix at the centre of the curve either side with one screw (x) as shown in Fig. 1

Carefully position the roof assembly to enable one of the Side Sections (A) to be fitted. Using two screws (x) in each side, attach the Side Section to the roof assembly.



# STEP 4


Turn this assembly to allow the other side assembly to be fitted.

The arch may now be positioned into the prepared holes.

Ensure the arch is vertical and square.

#### STEP 7

Fill the holes with the chosen method of fixing.



### **AFTERCARE**

To ensure longevity of your structure it is recommended that it is treated with a wood preservative on a yearly basis.

